





# Compatibility Chart

Last update: Oct 2015

## Nikon Cameras

	D2Xs	D3 / D3X	D3s	D4	D4s	D40 / D40X	D50	D60	D70 / D70s	D80	D90	D200	D300	D300s	D600	D610	D700	D750	D800	D800E	D810	D3000	D3100	D3200	D3300	D5000	D5100	D5200	D5300	D5500	D7000	D7100	Df	Coolpix A	Coolpix P5000	Coolpix P5100	Coolpix P7700	
Nissin Model																																						
Di866	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	○	●	●	●	●	●	●	●	●	●	●	●	○	●	●	●	○	○	○	○	○
Di622 Mark II	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	○	○	○	○	○
Di622	○	●	○	○	○	●	●	●	●	●	●	●	●	○	○	●	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
Di466	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	○	○	○	○	○
Di28	●	●	○	○	○	●	●	●	●	●	●	●	●	●	●	●	●	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○

- Compatible Model
- Latest Firmware is Required
- FV Lock system does not work

