

Nikon Cameras																																																										
	Z7	Z6 II	Z6	D5 -	D4s	D4	D3x	D3s	D3	D2Xs	D2Hs	D2H	D1	Df	D850 -	D810	D800E	D800	D780	D750	D700	D610	D600	D500 -	D300s	D300	D200	D100	D7500 -	D7200	D7100	D7000	D5600 -	D5500	D5300	D5200	D5100	D5000	D3400 -	D3300	D3200	D3100	D3000	D90	D80	D70 / D70s	D60	D50	D40 / D40X	Coolpix A	Coolpix P7700	Coolpix P5100	Coolpix P5000					
Nissin Model																																																										
MG80 Pro New	●	●	●	●	●	●	●	●	●	○	○	○	○	○	●	●	●	●	●	○	●	●	●	●	●	●	●	○	-	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	○	○	○	○					
Air 10s Commander	●	●	●	●	●	●	●	●	●	○	○	○	○	○	●	●	●	●	●	●	●	●	●	●	●	●	●	○	-	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	○	○	○	○				
Air 1 Commander	○	○	○	*1	*2	*2	●	●	●	○	○	○	○	○	●	●	●	●	○	●	●	●	●	●	●	●	○	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	○	○	○	○	○	○	○	○					
D700 A	●	●	●	●	●	●	●	●	○	○	○	○	○	○	●	●	●	●	○	●	●	●	●	●	●	●	●	○	-	●	●	●	●	●	●	●	●	●	○	●	●	●	●	●	●	●	●	●	●	●	○	○	○	○				
i60A	●	●	●	●	●	●	●	●	○	○	○	○	○	○	●	●	●	●	●	●	●	●	●	●	●	●	○	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	○	○		
i600	●	●	●	●	●	●	●	●	○	○	○	○	○	○	●	●	●	●	●	●	●	●	●	●	●	○	-	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	○	○	
i40	●	●	●	●	●	●	●	●	○	○	○	○	○	○	●	●	●	●	●	●	●	●	●	●	●	○	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	○	○
i400	●	●	●	●	●	●	●	●	○	○	○	○	○	○	●	●	●	●	●	●	●	●	●	●	●	○	-	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	○	○
MF18	○	○	○	●	●	●	●	●	○	○	○	○	○	○	●	●	●	●	○	●	●	●	●	●	●	○	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	○	○	○	○	○	○	○	○		
MG8000 Extreme (discontinued)	○	○	○	●	●	●	●	●	○	○	○	○	○	○	●	○	●	●	●	●	●	●	●	●	○	●	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
D1866 Mark II (discontinued)	○	○	○	*3	●	●	●	●	○	○	○	○	○	○	●	○	●	●	○	●	●	●	●	●	○	●	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
D700 (discontinued)	○	○	○	○	●	●	●	●	○	○	○	○	○	○	●	○	●	●	○	●	●	●	●	○	●	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
D1600 (fade out model)	○	○	○	○	●	●	●	●	○	○	○	○	○	○	●	○	●	●	○	●	●	●	●	○	●	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	

- Compatible Model
- Incompatible Model
- No information available. To be confirmed.

*1 Extremely underexposure (about -2EV) appear when Air 1 mounted on D5 to control wirelessly the slave flash and the flash light does not hit the subject directly, such as bouncing or diffusing.
 *2 In D4 · D4s, when manual flash is set, when you shoot continuously and rapidly manually in the Q mode - 1 sheet shooting mode, emission may be missing. Please understand that it is based on specifications.
 *3 At the time of FP flash, it may be underexposed by about 1 stage compared with the genuine strobe
 *4 SD Mode not supported
 *5 Commander / Flash unit may be freeze when camera turn on the electronic shutter mode with mirror up mode. If Commander / Flash unit freezes, remove and re-insert the battery. Turn off the in-compatible function of camera then power on Commander / Flash unit again.
 *6 A firmware update may required in the future.

Note
 1. AF-assist lamp is not supported on Mirrorless cameras.

	Nissin Flashes								Nikon Flashes							
	i40 Nikon	D1466 Nikon	D1600 Nikon	D1622 Mark II Nikon	D1700 Nikon	D1866 Nikon	D1866 Mark II Nikon	MG8000 Nikon	SB-500	SB-600	SB-700	SB-800	SB-900	SB-910	SB-5000	
Air R Receiver Nikon	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	

- Compatible Model
 - Air R's GN Mode. 25-49
 - Air R's GN Mode. 50-65
- *5 FP/HSS high speed sync function not supported

Nissin DIGITAL		Compatibility Chart																												Last update: Mar 2021	
		Olympus Micro Four Thirds / Four Thirds Cameras																													
		E-M1 Mark II (OMD)	E-M1 (OMD)	E-M5 Mark II (OMD)	E-M5 (OMD)	E-M10 Mark III (OMD)	E-M10 Mark II (OMD)	E-M10 (OMD)	PEN-F	E-P5	E-P3	E-P2	E-P1	E-PL8 New	E-PL7	E-PL6	E-PL5	E-PL3	E-PL2	E-PL1	E-PM2	E-PM1	E-620	E-520	E-500	E-410	E-30				
Nissin Model																															
Air 10s Commander New (Four Thirds ver.)		●	●	●	●	●	—	●	—	●	●	●	●	●	—	●	●	—	●	●	●	●	—	—	—	—	—				
Air 1 Commander (Four Thirds ver.)		●	●	●	●	○	●	●	+	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●				
D1700 A (Four Thirds ver.)		●	●	● ^{*3}	●	○	●	●	+	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●				
i60A (Four Thirds ver.)		●	●	● ^{*1}	●	○	●	●	+	●	●	●	●	●	●	●	●	●	●	●	●	●	● ^{*2}	● ^{*2}	● ^{*2}	● ^{*2}	● ^{*2}				
i600 (Four Thirds ver.)		●	●	● ^{*1}	●	○	●	●	+	●	●	●	●	●	●	●	●	●	●	●	●	●	● ^{*2}	● ^{*2}	● ^{*2}	● ^{*2}	● ^{*2}				
i40 (Four Thirds ver.)		● ^{*1}	●	● ^{*1}	●	● ^{*4}	●	●	+	●	●	●	●	●	●	●	●	●	●	●	●	●	● ^{*2}	● ^{*2}	● ^{*2}	● ^{*2}	● ^{*2}				
i400 (Four Thirds ver.)		● ^{*1}	●	● ^{*1}	●	● ^{*4}	●	●	+	●	●	●	●	●	●	●	●	●	●	●	●	●	● ^{*2}	● ^{*2}	● ^{*2}	● ^{*2}	● ^{*2}				
D1466 (Four Thirds ver.)		—	●	○	●	—	○	●	○	●	●	●	●	—	○	●	●	●	●	●	●	●	●	●	●	●	●				

- Compatible Model
 - Incompatible Model
 - No information available. To be confirmed.
- *1 Unstable operation may appear when turn on the S-OVF Function (Optical view finder simulation) of EVF and shoot with EVF.
 *2 Flash's optical slave wireless mode is incompatible with camera's wireless flash system.
 *3 D1700A for FT version will be supporting Olympus E-M5 Mark II after flash firmware updated.
 *4 Hardware compatible on or above the following Serial Number: i40: 8A18XXXXXXX~ i400:8927XXXXXXX~

Note
 1. AF-assist lamp is not supported on Mirrorless cameras.

Nissin DIGITAL		Compatibility Chart																												Last update: Mar 2021	
		Panasonic Micro Four Thirds Cameras *4																													
		GH5	GH4	GH3	GH2	GH1	GX8	GX7	GX7 Mark II / GX85 / GX80	GX1	G10	G9	G8 / G80 / G85	G7 / G70	G6	G5	G3	G2	G1	GF2	GF1	LX100	LX7	LX5	LX3	FZ100					
Nissin Model																															
Air 10s Commander New (Four Thirds ver.)		●	—	●	—	●	—	●	—	—	—	●	—	—	●	—	—	●	●	●	●	—	●	●	●	●					
Air 1 Commander (Four Thirds ver.)		●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●					
D1700 A (Four Thirds ver.)		●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●					
i60A (Four Thirds ver.)		●	—	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●					
i600 (Four Thirds ver.)		●	—	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●					
i40 (Four Thirds ver.)		●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●					
i400 (Four Thirds ver.)		●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●					
D1466 (Four Thirds ver.)		—	●	●	●	●	○	●	○	●	●	—	—	○	●	●	●	●	●	●	●	●	●	●	●	●					

- Compatible Model
 - Incompatible Model
 - No information available. To be confirmed.
- *4 According to the specifications of Panasonic Lumix series, the continuous shooting function cannot be used when an external flash is installed on the hot shoe.

Note
 1. AF-assist lamp is not supported on Mirrorless cameras.

Fujifilm Cameras																																
	GFX 50s	X-H1	X-T4	X-T3	X-T2	X-T1 / X-T1 GS	X-T20	X-T10	X-Pro2	X-Pro1	X-E3	X-E2S	X-E2	X-E1	X-M1	X-A5	X-A3	X-A2	X-A1	X100F	X100T	X100S	X100	X70	X30	X20	X10	X-S1	HS50EXR	HS30EXR	HS20EXR	
Nissin Model																																
Air 10s Commander	—	●	●	●	●*1	●*1	●	●	●*1	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	—
Air 1 Commander	●*1 *2	●	●	●	●*1	●*1	●	●	●*1	●	●	●	●	●	●	○	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	○
D1700 A	●*1 *2	●	●	●	●*1	●*1	●	●	●*1	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	○
i60A	●*1 *2	●	●	●	●*1	●*1	●	●	●*1	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	○
i600	●*1 *2	●	●	●	●*1	●*1	●	●	●*1	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	○
i40	●*1 *2	●	●	●	●*1	●*1	●	●	●*1	●	●	●	●	●	●	○	○	●	●	●	●	●	●	●	●	●	●	●	●	●	●	○
i400	●*1 *2	●	●	●	●*1	●*1	●	●	●*1	●	●	●	●	●	●	○	○	●	●	●	●	●	●	●	●	●	●	●	●	●	●	○

- Compatible Model
- Incompatible Model
- This camera supports HSS/FP High speed synchronize function.

*1 The Fujifilm camera is supporting of High speed synchronize function after camera firmware updated
 *2 Flash can be insert on the hot shoe of main body or that of EVF. When inserted a flash on the EVF shoe, do not tilt-up EVF since this may make the EVF damage.

Note
 1. AF-assist lamp is not supported on Mirrorless cameras.